

IBU2 Ultimate and EIMod connection for 4th generation Heng Long tanks

Please read these installation instructions **before** you start the installation and observe our instructions.

ATTENTION!

Observe the points described in this manual. Failure to comply will void any warranty. The liability will be transferred to you as soon as you start the conversion.

upper hull connector



cables from airsoft BB unit



1x cable red/blue
1x cable red/black

The cable must be rewired as follow:

cable red/blue

- blue wire in No. 2
- red wire in No. 4

cable red/black

- black wire in No. 1
- red wire in No. 3

Other cable red/black from shoot/sound switch from airsoft unit won't need to be changed.

The RCTank team wishes every success.